



1. RubberBond FleeceBack EPDM with FAT
2. RubberBond Decking Adhesive
3. 150mm PS Cover Strip
4. Suitable thermal insulation, thickness determined by U-value
5. Vapour Control Layer (VCL)
6. Structural decking
7. Pitched roof under lay by others
8. Roof tile by others
9. Lead flashing by others

Notes:

1. This detail was prepared to serve as a guideline representing typical detailing conditions and illustrate the correct application of RubberBond products only. It may be necessary to modify this detail in whole or part in accordance with specific project conditions, design or requirements.
2. See option 2 for installation using 150mm PS Cover Tape for seaming to drip trim



Roofing the world for 50 years
www.rubberbond.co.uk

Title
FLAT ROOF TO PITCH ROOF LEAD
TERMINATION (MANSARD)

Product
RB-T-3

Drawn	Checked	Approved	Scale	Date
MFO	DW	DW	1: 4@A4	17.10.12

Status
PRODUCTION

Drawing No:	Rev:
RB/T/3	A

A	17.10.12	PRODUCTION Issue
Rev	Date	Comments